



Hot Dog Steamer Operating Instructions:

Preparation: Install the machine in a level position. Plug into a standard 110 outlet. Use room temperature hot dogs - NOT FROZEN.

1. Add approximately ten quarts of water into the steaming compartment so the water level is above the heating element. Using hot water will reduce the heating time. DO NOT OVERFILL.
2. Place hot dogs in small compartment and buns in the wire rack in the large compartment. Arrange the hot dogs and buns to allow free circulation of steam.
3. Turn the switch to "ON" position and set the thermostat control on "HIGH" until steam is generated.
4. For normal operation, set the thermostat control in the center range between "LOW" and "HIGH". When not serving, keep the lids closed. And add more hot water as necessary to maintain the water level.